

Work Order ID 62256

Thursday, September 23, 2010 12:41:24 PM

Page 1

Item ID: D350-567-111

Accept

Setup Start

Revision ID:

Stop

Item Name: Floor Window Installation, Extra Large

Start Date: 9/23/2010 Start Qty: 4.00

Cust Item ID:

Required Date: 10/12/2010 Req'd Qty: 4.00

Customer:

Reference:

Approvals:

Process Plan:

Date: 10-9-23

Tooling:

Date:

QC:

Date:

SPC (Y/N):

Date:

Run Start

Stop

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
Draw Nbr	Revision Nbr								
IIN-D350-567	Rev D								

100

0.00



DOCUMENT CONTROL

DC

Memo

0.00

Document Control

Photocopy bluefile and create labels and DT8439 Template per PPP D350-567-111 CHG006

8/10/10/14

JJ For BG 10-9-28

110

0.00



Packaging

Packaging

Memo

0.00

Packaging

Pick Packing Kit

ENSURE DT 8439 TEMPLATE IS INCLUDED

Soliday

10/9/28 SP (4)

120

0.00



QC4- 100% Inspect kits for completeness

QC

Memo

0.00

Quality Control

8/10/10/14

(x4)

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 62256

Thursday, September 23, 2010 12:41:24 PM

Page 2

Item ID: D350-567-111

Accept

Setup Start

Revision ID:

Stop

Item Name: Floor Window Installation, Extra Large

Start Date: 9/23/2010 Start Qty: 4.00

Cust Item ID:

Required Date: 10/12/2010 Req'd Qty: 4.00

Customer:

Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Run Start

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop

Sequence ID/
Work Center IDOperation
DescriptionSet Up/
Run Hours

Tool ID

Tool #

Plan
CodeAccept
QtyReject
QtyReject
NumberInsp.
Stamp

130

0.00



Packaging

Packaging

Memo

0.00

Packaging

Identify and pack for shipping as per PPP D350-567-111
Location: _____*Hub*

140

QC21- Final Inspection - Work Order Release

0.00



QC

Memo

0.00

Quality Control

*C 01/10/15 (y)**10/10/05**W 10-10-05*

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

Thursday, September 23, 2010 12:41:28 PM

Page 1

Work Order ID: 62256



Parent Item: D350-567-111



Parent Item Name: Floor Window Installation, Extra Large

Start Date: 9/23/2010

Required Date: 10/12/2010

Start Qty: 4.00

Required Qty: 4.00

Comments: IPP Rev:C Re-format 05-11-09 JLM
 IPP Rev:D Added DT8439 Template to Step 1 07-06-26 JLM
 IPP Rev:E CHG#3 ECN 1055 07-11-21 DD verified by:EC
 IPP Rev:F 08-10-07 as per revD DD verified by:

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D350-567-113 Replacement Window, Extra Large	CHC7003	Manufactured	No			110	Each	0.0000	1	4		B62258 10/9/09	
D350-567-115 Interior Floor Window	CHC7004	Manufactured	No			110	Each	1.0000	1	4		B62257 10/9/09	
<div> <div>DT8439 template</div> <div> <div>Location</div> <div>FG</div> <div>60682</div> </div> <div> <div>Loc Qty</div> <div>1</div> <div>1</div> </div> <div> <div>Loc Code</div> <div></div> <div></div> </div> </div>													
		Manufactured	No			110	Each	0.0000	1	4			

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

5.0 PARTS LIST

Qty -015	Qty -017	Qty -025	Qty -027	Qty -111	Qty -117	Part Number	Description
X						D350-567-015	FLOOR WINDOW INSTALLATION (SMALL)
	X					D350-567-017	FLOOR WINDOW INSTALLATION (SMALL)
		X				D350-567-025	FLOOR WINDOW INSTALLATION (LARGE)
			X			D350-567-027	FLOOR WINDOW INSTALLATION (LARGE)
				X		D350-567-111	FLOOR WINDOW INSTALLATION (EXTRA LARGE)
					X	D350-567-117	FLOOR WINDOW INSTALLATION (EXTRA LARGE)
1	1					D350-567-013	REPLACEMENT WINDOW KIT (SMALL)
		1	1			D350-567-023	REPLACEMENT WINDOW KIT (LARGE)
				1	1	D350-567-113	REPLACEMENT WINDOW KIT (EXTRA LARGE)
	1		1	1		D350-567-115	INTERIOR FLOOR WINDOW KIT
1		1			1	D350-567-031	INTERIOR FLOOR WINDOW KIT (SLIDING DOOR COMPATABLE)

Qty -013	Qty -023	Qty -113	Qty -115	Qty -031	Part Number	Description
X					D350-567-013	REPLACEMENT WINDOW KIT (SMALL)
	X				D350-567-023	REPLACEMENT WINDOW KIT (LARGE)
		X			D350-567-113	REPLACEMENT WINDOW KIT (EXTRA LARGE)
			X		D350-567-115	INTERIOR FLOOR WINDOW KIT
				X	D350-567-031	INTERIOR FLOOR WINDOW KIT (SLIDING DOOR COMPATABLE)
1					D2125	REPLACEMENT WINDOW, SMALL
	1				D2942	REPLACEMENT WINDOW, LARGE
		1			D3290-041	REPLACEMENT WINDOW ASSEMBLY, EXTRA LARGE
1					D2126-0600	SEAL
	1				D2463-0750	NEOPRENE SEAL
		1			D2463-0860	NEOPRENE SEAL
	9	12			2600-6	1/4 TURN FASTENER
	9	12			2600-LW	WASHER
	9	12			212-12	RECEPTACLE
	22	21			AN526C832R9	SCREW (OR AN526C832-9, OR MS51957-126)
	44	42			AN960JD8	WASHER
	22	21			MS21042L08	NUT (OR MS21042-08)
	18	24			MS20426AD3-5	RIVET
2 SQ. YD	2 SQ. YD	2 SQ. YD			N/A	9.7oz 7781 'S' GLASS UNIVERSAL WEAVE
				1	D2463-0450	NEOPRENE SEAL
				1	D3210-1	DOUBLER
				1	D3211-1	BRACKET
				1	D3212-1	FLOOR WINDOW
				1	D3213-041	DOOR ASSEMBLY
			1		D3293-1	DOUBLER
			1		D3294-1	BRACKET
			1		D3295-041	FLOOR WINDOW
			1		D3296-041	DOOR ASSEMBLY
			1		D2463-0530	NEOPRENE SEAL
		9	8		AN526C632R12	SCREW (OR AN526C632-12, OR MS51957-32)
		9	8		AN960JD6	WASHER
		9	8		MS21042L06	NUT (OR MS21042-06)
			2	40	MS20470AD4-5	RIVET
			115	90	MS20470AD4-6	RIVET
			15	20	MS20470AD4-7	RIVET